

Endless Summer Sun

Bamboo Island Tiki Bars

Bamboo Tiki Bar Stools • Artificial Palm Trees

Palm Tree Installation Instructions

For large custom trees over 14ft, please call or email for special instructions

For Concrete Installation



Carefully remove Palm Tree from container and place it upright where it will be installed. After positioning is complete, drill down through existing holes of the base using a ½ inch masonry bit. Drill 4 inches deep.

Gently tap the enclosed concrete bolts through the base into the concrete and tighten the nut. Be careful not to over tighten the bolt, too much torque can break the bolt.

If pouring a new pad, refer to these specs:

(For stock trees, 8, 10, 12, and 14 ft tall)

It is recommended to dig a hole 30" x 30" x 12" deep. Drive six 2 foot long rebar stakes into the hole leaving 4" to 6" of the rebar exposed in the hole so that when the concrete is poured and cured, the new concrete pad is "anchored" to the ground. This pad will accommodate up to three palm trees.

Important to remember! The palm trees are very top heavy and will catch a lot of wind. Be safe, and don't skimp on the dimensions. Remember to check local codes before digging!



For Wood Deck Installation

Carefully remove Palm Tree from container and place it upright where it will be installed making sure you have the tree positioned over deck joist so that at least 2 of the 4 lag screws will catch the joist. After positioning is complete, use the enclosed lag screws and washers. Place one washer on the lag screw and screw into wood and down into the joist. Repeat for the other 3 holes.

Be careful not to over tighten, too much torque can cause the lag screw to "strip" out the hole and cause the tree not to be secure.

Endless Summer Sun
9 Main St., Chester, NJ 07930
Phone (908) 235-1848